

Shoes

Maintenance

Daily maintenance

After using, remove and dry the insole.

Please remove wetness to prevent deterioration of the shoes because we are likely to sweat at foot.

After using in the rain, remove the insole and stuff the shoes with a rolled newspaper to dry them quickly.

If there is dirt on the surface, please remove it with a brush and keep it.

We recommend brushing because especially mesh shoes are easy to catch small dirt in the mesh hole.



Removal dirt

If it is difficult to remove the dirt only by brushing, please wash with a neutral detergent or cleaner for shoes. At this time, please be careful not to put water in your shoes as much as possible. Putting water in the shoes will be a cause of deterioration due to dry slowly. After removing the dirt, wipe wetness on the surface off and keep it at a well-ventilated place out of direct sunlight.

We recommend spraying a fluorine-based spray to prevent dirt.



Repair service

TAICHI shoes is adopted BOA fit system that makes it easy to put on and take off the shoes.

If the dial or wire part breaks down, most cases can be repaired.

Inquiries about repairs and shipping address for repair requests

RS TAICHI customer support

〒578-0901 Kakou3-4-7 Higashiosaka city, Osaka, Japan

TEL:0120-22-3403

Reception time

Week day: 10:00~17:30(JST)*Excluding weekends, public holidays, year-end and New Year